





PAGE NOTES:

- ① TOUCH SCREEN USER INTERFACE
- ② MODULE STATUS INDICATOR
- ③ COMMUNICATION STATUS INDICATOR
- ④ REMOVABLE PANEL COVERS FOR FIELD WIRING
- ⑤ COMMUNICATION INTERFACE COVER (BLACK-DO NOT REMOVE)
- ⑥ RELAY OR DIMMING MODULES
- ⑦ COMMUNICATION INTERFACE CARD (DO NOT REMOVE)
- ⑧ INTERCONNECT CARD (DO NOT REMOVE)

FRONT VIEWS

INSIDE VIEWS






RD-32 RELAY PANEL
SCALE: N.T.S

RD-48 RELAY PANEL
SCALE: N.T.S

RD-32 RELAY PANEL
SCALE: N.T.S

RD-48 RELAY PANEL
SCALE: N.T.S

PART#	RD-48 & RD-32	
DESC.	RD (1 OF 3)	
DWG#	1-RD	
DATE:	10/16/15	REV. 16-4
		DRAWING BY: TDP



RD-32 RELAY PANEL DIMENSIONS
SCALE: N.T.S

RD-48 RELAY PANEL DIMENSIONS
SCALE: N.T.S

RD PANEL WIRING
SCALE: N.T.S


PART#	RD-48 & RD-32		
DESC.	RD (2 OF 3)		
DWG#	2-RD		
DATE:	10/16/15	REV.	16-4
		DRAWING BY:	TDP

www.touchecontrols.com
phone: 1-888-841-4356

Touché

LIGHTING CONTROL

TOP OF RD PANEL



RIGHT SIDE MODULE
INSTALLATION

LEFT SIDE MODULE
INSTALLATION



RD PANEL MODULE WIRING
SCALE: N.T.S

PART#	RD-48 & RD-32	
DESC.	RD (3 OF 3)	
DWG#	3-RD	
DATE:	10/16/15	REV. 16-4
DRAWING BY:	TDP	

www.touchecontrols.com
phone: 1-888-841-4356

Touché
LIGHTING CONTROL