


TOUCHÉ LIGHTING CONTROL

ONE SOLUTION™



PARTITIONED ROOMS

EXAMPLE

4 ROOMS



TOUCHÉ LIGHTING CONTROL

ONE SOLUTION™

Touché Components



RM Room Manager

Networked Room Controller



Wall Station

Color Mini



Smart Load Control

Dimmable



Smart Sensor

Dual technology (PIR/passive acoustic) occupancy / vacancy sensor with built-in photo sensor.




PS Partition Sensor

Digital Input Partition Sensor

Cable Type

---- **CAT5** (minimum)





To make a room partitionable:

- 1 Add a partition sensor to one of the Room Managers
- Connect the Room Managers with an Ethernet cable.

